

## DIN 371 & DIN 376

Voor blinde gaten // Pour trous borgnes



<b>AFM. // DIM.</b>	<b>18.371.XX.35</b>	<b>18.376.XX.35</b>
M3 X 0,50	•	x
M4 X 0,70	•	x
M5 X 0,80	•	x
M6 X 1,00	•	x
M8 X 1,25	•	x
M10 X 1,50	•	x
M12 X 1,75	x	•
M14 X 2,00	x	•
M16 X 2,00	x	•
M18 X 2,50	x	•
M20 X 2,50	x	•
M22 X 2,50	x	•
M24 X 3,00	x	•